

TYPICAL TRACK - SECTOR FORMAT

### DISK AND CONTROLLER

The disk controller is designed to accommodate one of a variety of DIABLO disters, including models 31 and 44. Each drive accommodates one or two disks. Each two heads, one per side. Information is recorded on each disk in a 12-sector on each of up to 406 (depending on the disk model) radial track positions. The disk contains up to 9744 recording positions (2 heads X 12 sectors X 406 traces Figure 1 tabulates various useful information about the performance of the disk was.

DEVICE	DIABLO 31	DIABLO 44	
Number of drives/Alto	1 or 2	1	
Number of packs	1 removable	l removable	
		1 fixed	
Number of cylinders	203	406	
Tracks/cylinder/pack	2	2	
Sectors per track	12	12	
Words per sector	2 header	2 header	
	8 label	8 label	
	256 data	256 data	
		en e	
Data words/track	3072	3072	
Sectors/pack	4872	9744	
Rotation time	40	25	36
			· •
Seek time (approx.)	15 + 8.6*sqrt(dt) 15-70-135	8 + 3*sqrt(dt) 8-30-68	<b>*</b>
min-avg-max	80	32 (using both packs	- 시설 - 신화
Average access to 1 megabyte	80	32 (using both packs)	*#.3*
Transfer rate:			
peak/avg	1.6/1.22	2.5/1.9	% 1 <b>2</b>
peak/avg	10.2/13	6.7/8	word
per sector	3.3	2.1	<b>.</b>
for full display	.460	.266	e7 <b>2</b>
for 64K memory	1.03	.6	3.50
whole drive	19.3	44 (both packs)	≲ ≅ <b>C</b>

\*The notation dt stands for the number of tracks traveled during the seek.

#### FIGURE 1

The disk controller records three independent data blocks in each sector. The first is two words long, and is intended to include the address of the sector. This block is called the Header block. The second block is eight words long, and is called the Label block. The third block is 256 words long, and is the Data block. Each block may be independently read, written, or checked, except that writing, once begun, must continue until the end of the sector.

When a block is checked, information on the disk is compared word for word with specified block of main memory. During checking, a main memory word containing has special significance. When this word is encountered, the matching word read from the disk is stored in its place and does not take part in the check. This feature permits a combination of reading and checking to occur in the same block. (It also has the drawback of making it impossible to use the disk controller to check for words containing 0 on the disk).

The Alto program communicates with the disk controller via a four-word block of main memory. The first word is interpreted as a pointer to a chain of disk command blocks. If it contains 0, the disk controller will remain idle. Otherwise, the disk controller will commence execution of the command contained in the first disk command block. When a command is completed successfully, the disk controller stores a pointer to the next command in the chain and the cycle repeats. If a command terminates in error, a 0 is immediately stored and the disk controller idles. At the beginning of each sector, status information, including the number of the current sector, is stored. This can be used by the Alto program to sense the readiness of the disk and to schedule disk transfers, for example. When the disk controller begins executing a command, it stores the disk address of that command. This information is later used by the disk controller to decide whether seek operations or disk switches are necessary. It can be used by the Alto program for scheduling disk arm motion. If the Alto program stores an illegal disk address (like -1) in this word, the disk controller will perform a seek at the beginning of the next disk operation. (This is useful, for example, when a disk driver wants to force a restore operation). The disk controller also communicates with the Alto program by interrupts.

A disk command block is a ten-word block of memory which describes a disk transfer operation to the disk controller, and which is also used by the controller to record the status of that operation. The first word is a pointer to the next disk command block in this chain. A 0 means that this is the last disk command block in the chain. When the command is complete, the disk controller stores its status in the second word. The third word contains the command itself, telling the disk controller what to do. The fourth word contains a pointer to the block of memory from/to which the header block will be transferred. The fifth word contains a similar pointer for the label block. The sixth word contains a similar pointer for the data block.

The seventh and eighth words of the disk command block control the initiation of interrupts when the command block is finished.

The ninth word is unused by the disk controller, and may be used by the Alto program to facilitate chained disk operations. The tenth word contains the disk address at which the current operation is to take place.

DCB: Pointer to next command block.

DCB+1: Status. DCB+2: Command.

DCB+3: Header block pointer. DCB+4: Label block pointer.

DCB+5: Data pointer.

DCB+6: Command complete no-error interrupt bit mask.

DCB+7: Command complete error interrupt bit mask.

DCB+8: Currently unused.

DCB+9: Disk address.

## A disk address word A contains the following fields:

FIELD	RANGE	SIGNIFICANCE
A[0-3]	0-13B	Sector number.
A[4-12]	0-625B (Model 44) 0-312B (Model 31)	Cylinder number.
A[13]	0-1	Head number.

FIELD	RANGE	SIGNIFICANCE
A[14]	0-1	Disk number (see also C[15]). O is removable pack on Model 44. 1 is optional second Model 31 drive.
A[15]	0-1	<pre>0 normally. 1 if cylinder 0 is to be addressed via a hardware "restore" operation.</pre>


 ${\tt A}$  disk command word  ${\tt C}$  contains the following fields:


FIELD	RANGE	SIGNIFICANCE
C[0-7]	110B	Checked to verify that this is a valid disk command.
C[8-9]	0-3	0 if Header block to be read. 1 if Header block to be checked. 2 or 3 if Header block to be written.
C[10-11]	0–3	0 if Label block to be read. 1 if Label block to be checked. 2 or 3 if Label block to be written.
C[12-13]	0-3	O if Data block to be read. 1 if Data block to be checked. 2 or 3 if Data block to be written.
C[14]	0-1	O normally.  l if the command is to terminate immediately after the correct cylinder position is reached (before any data is transferred).
C[15]	0-1	XOR'ed with A[14] to yield hardware disk number.

# ${\tt A}$ disk status word ${\tt S}$ has the following fields:

FIELD	VALUES	SIGNIFICANCE
S[0-3]	0-13B	Current sector number.
S[4-7]	17В	One can tell whether status has been stored by setting this field initially to 0 and then checking for non-zero.
S[8]	0-1	l means seek failed, possibly due to illegal cylinder address.
S[9]	0-1	1 means seek in progress.
S[10]	0-1	l means disk unit not ready.

FIELD	VALUES	SIGNIFICANCE
s[11]	0-1	l means data for sector processing was late during the last sector. Data and current sector number unreliable.
S[12]	0-1	l means disk interface was not transferring data last sector.
S[13]	0-1	l means checksum error. Command allowed to proceed.
S[14-15]	0-3	O means command completed correctly.  1 means hardware error (see S[8-11]) or sector overflow.  2 means check error. Command terminated instantly.  3 means disk command specified illegal sector.






Xerox Corporation 701 South Aviation Boulevard El Segundo, California 90245 213 679-4511




late	Prawing		<b>V</b>			16389	]
<b>D</b>		LTO II SSEMBLY, PRINTED WIRING-	These drawings and spe in, are the exclusive pr Xerox, Ltd. issued in str prior written permission be reproduced, copied or the manufacture of article	operty of ict confid of Xerox ( used for as for Xero	Xerox Corp lence and si Corporation any purpose	oration and, hall not, wit or Rank Xero whatsoever	or Ran hout th ox, Ltd
ا يو		DISK CONTROL	Model No ALTO II	Date	5/14/76	Sheet	4 <sub>Of</sub>
216389	Item No.	Drawing Title	Drawing No.	No. Req	•	Remarks	
7	1	BOARD, PRINTED WIRING	216391	1			
J E	2	SPEC, TEST	216390	REF			
2	3	SPEC, MODULE ASSEMBLY	216207	REF			
-	4	MICROCIRCUIT, MPQ3303		1	Al		
-	5	74H04		3	A2,56	, 59	
	6	3205		1	A3		
	7	74LS08		4	A4,5,6	,7	
1	8	74H00		1	A11		
	9	74S04		1	A12		
	10	74164		2	Å13, 18	3	
L	11	8T10		6	A14, 15,	16, 17, 40	5, 47
	12	74166		2	A19,39		
	13	7437		5	A20, 30	, 40, 58, 6	8
	14	74109		8	A21, 22,	43, 44, 45	5, 53,
			•.		55,67		
	15	74532		2	A23, 57	7	
	16	7438		2	A24, 34		
	17	74174		3	A25, 2	5, 27	
	18	74123		2	A31,5		
	19	7400		2	A33, 6		
	20	I3404		1	A35		
	21	74195		2	A36, 37	,	<del></del>
	22	74H08	-	2	A38, 42	)	
	23	<i>74</i> H11		1	A41	<del> </del>	
	24	8231		2	A48, 49		
	25	74H01		2	A50,60	)	
	26	74502		1	A54	1	
	27	7414		1	A61		
ſ	28	74H 106		1	A64		
	29	74153		1	A65		
	30	MICROCIRCUIT, 74161		1	A69		
	31	OSCILLATOR, K1100A 3.33	3 MH	1	A62		
r	32			+	<del>                                     </del>		




Nate	rial L	ist	,	7		Γ	ML	Drawing No. 216	389	Rev. J
J.		.TO II SEMBLY,	PRINTED WIRING-	in, are Xerox, prior v be rep the ma	drawings and speci the exclusive pro Ltd. issued in stric written permission or roduced, copied or u nufacture of articles	perty of at confide f Xerox C sed for a s for Xero	Xerox ence Corpo eny pi	Corporationand shall not read and shall not read and read	n and/or ot, withous nk Xerox, soever, e ank Xerox	Rank ut the Ltd., xcept
<u>.</u> & L				Model N	ÄLTO II	Date 6	/14	/76	Sheet 5	Of
216389	tem No.		Drawing Title		Drawing No.	No. Req.		Ren	arks	
7	33		OR, NETWORK, DIP, $270\Omega$ (AB#316)			1	+	.9		
	34	RESISTO	OR, NETWORK, DIP, $560\Omega(AB^{\#}31c)$	5A561)		1	1	48		
Z	35	RESISTO	OR, NETWORK, $470\Omega$ , (CTS $\#750-8$	31-R470	<b>)</b>	2	A	190,91		
L	36	RESISTO	R, FILM, 39Ω ±5%, 1/4W		116447-390	2	R	1,R2		
L	37		200 Ω ±5%, 1/4W		116447-201	5	RS	3, 4, 5, 6,	12	
	38		24K ±5%, 1/4W		116447-243	2	R7	7,8		
	39		15K ±5%, 1/4W		116447-153	1	R9			
	40		30K ±5%, 1/4W		116447-303	1	R 10	0		
Ī	41		330 Ω ±5%, 1/4W		116447-331	2	R1	1, R20		
Γ	42		560 Ω ±5%, 1/4W		116447-561	1	RI	8		
Ī	43		270 Ω ±5%, 1·/4W		116447-271	1	R 1	9		
r	44	RESISTO	R, FILM, 1K ±5%, 1/4W		116447-102	5	R1:	3, 14, 15,	16, 17	
	45									
	46	DIODE.	IN4148			2	CF	1, CR2		
T	47	<u>-</u>	ZENER, IN5227			1	VF		<del></del>	
F	48						<del>                                     </del>			
F	49	CAPAC	ITOR, 150PF NYTRONICS DC 151			1	<del> </del> c	1		
F	50		ITOR, .01µF			2	ļ	2,C4		
	51		ITOR, .47µF ±20%, 50V		114491-474	<del>  -</del>	C	·		
-	52		TOR, 270PF NYTRONICS DC 27	<u>'1</u>		<u> </u>	C			
F	53		TOR, TANT., 22µF ±20%, 15V		114491-226	1	C			
 	54		TOR, .05µF, 10V CENTRALAB#U	K 10-50		61	03	1 17 10	21 27	40.4
 	-		TON, JOSET, TOV CERTIFICATION OF	10-50		01	43	1-17,19, -54,56-6 -79	0,62-7	<del>40,4</del>
H	55	CAPACTT	OR, .022 uF, 16V #DC222			<del>                                     </del>	C8			
-	56		ET, MICROCIRCUIT			31	1	UGAT#5	14-AG	100
<b> </b>	57		ET, MICROCIRCUIT			32		UGAT#5		
-	58	RIVET	, man oanou		156111-005	2	+~		.0-40	
F	59	EXTRA	CTOR		216250	2		<del></del>		
-	60	STIFFE	<del></del>			1	-			
F	<del>- 0</del> 0	211LLE	INEK	<del></del>	216242	1				
-						<del>                                     </del>	-			
L	106B/3/7									









WRITE S/R

These drawings and specifications, and the data contained therein, are the exclusive property of Xerox Corporation and/or Rank Xerox, Ltd. issued in strict confidence and shall not, without the prior written permission of Xerox Corporation or Rank Xerox, Ltd., be reproduced, copied or used for any purpose whatsoever, except the manufacture of articles for Xerox Corporation or Rank Xerox, Ltd.

ASSEMBLY, P.W.DISK CONTROL


Xerox Corporation
El Segundo, California

216389

Sheet 8 Of

1586(3/73)

Ā



These drawings and specifications, and the data contained therein, are the exclusive property of Xerox Corporation and/or Rank Xerox, Ltd. issued in strict confidence and shall not, without the prior written permission of Xerox Corporation or Rank Xerox, Ltd., be reproduced, copied or used for any purpose whatsoever, except the manufacture of articles for Xerox Corporation or Rank Xerox, Ltd.


ALTO ... II


ASSEMBLY, PRINTED W.

DISK CONTROL

Xerox Corporation El Segundo, California		XE	ROX	
216389			J	
Sheet	9	Of		

1586(3/73)






COMP. AND REG.

These drawings and specifications, and the data contained therein, are the exclusive property of Xerox Corporation and/or Rank Xerox, Ltd. issued in strict confidence and shall not, without the prior written permission of Xerox Corporation or Rank Xerox, Ltd., be reproduced, copied or used for any purpose whatsoever, except the manufacture of articles for Xerox Corporation or Rank Xerox, Ltd.

ASSEMBLY P.W. -

	orporation ndo, Californi	а	XE	ROX
	216389			. Ј
Sheet	10	Of		



These drawings and specifications, and the data contained therein, are the exclusive property of Xerox Corporation and/or Rank Xerox, Ltd. issued in strict confidence and shall not, without the prior written permission of Xerox Corporation or Rank Xerox, Ltd., be reproduced, copied or used for any purpose whatsoever, except the manufacture of articles for Xerox Corporation or Rank Xerox, Ltd.

ASSEMBLY, P.W. DISK CONTROL


Xerox Corporation
El Segundo, California

Z16389

Sheet

11 Of


1586(3/73)



These drawings and specifications, and the data contained therein, are the exclusive property of Xerox Corporation and/or Rank Xerox, Ltd. issued in strict confidence and shall not, without the prior written permission of Xerox Corporation or Rank Xerox, Ltd., be reproduced, copied or used for any purpose whatsoever, except the manufacture of articles for Xerox Corporation or Rank Xerox, Ltd.

ASSEMBLY, PW.-DISK CONTROL

Xerox Corporation El Segundo, California		XE	ROX	
	216	389		J
Sheet	12	Of		




Sheet


13

Of






Α





A



Sheet

16







DISK

These drawings and specifications, and the data contained therein, are the exclusive property of Xerox Corporation and/or Rank Xerox, Ltd. issued in strict confidence and shall not, without the prior written permission of Xerox Corporation or Rank Xerox, Ltd., be reproduced, copied or used for any purpose whatsoever, except the manufacture of articles for Xerox Corporation or Rank Xerox, Ltd.

ASSEMBLY, P.

DISK CONTRO.





~	_	_	$\overline{}$	v	
X	-	ĸ	( )	x	

		T	XEROX	
ELECTRICAL REF. DESIGNATIONS	ITEM	PART NO.	DESCRIPTION	QTY.
	1	218093	BOARD, PRINTED WIRING	1
	2	TAPE NO. 6389	TEST PROGRAM USED IN TERADYNE TESTER	RE
	3	216207	SPEC, MODULE ASSEMBLY	RE
A 1	4	MPQ3303	MICROCIRCUIT MOTOROLA	1
A2, 56, 59	5	74H04	MICROCIRCUIT, TI	3
A3	6	3205	MICROCIRCUIT, INTEL	1
A4,5,6.7	7	74LS08	MICROCIRCUIT TI	4
A11	8	74H00	MICROCIRCUIT TI	1
A12	9	74504	MICROCIRCUIT TI	1
A13,18	10	74164	MICROCIRCUIT TI	2
A14,15,16,17,46,47	11	8T10	MICROCIRCUIT SIGNETICS	6
A19,39	12	74166	MICROCIRCUIT TI	2
A20,30,40,58,68	13	7437	MICROCIRCUIT TI	5
A21,22,43,44,45,53	14	74109	MICROCIRCUIT TI	8
55,67				
A23,57	15	74\$32	MICROCIRCUIT TI	- 2
A24,34	16	7438	MICROCIRCUIT TI	2
A25,26,27	17	74174	MICROCIRCUIT TI	3
A31,52	.18	74123	MICROCIRCUIT TI	2
A33,63	19	7400	MICROCIRCUIT TI	2
A35	20	13404	MICROCIRCUIT INTEL	1
A36,37	21	74195	MICROCIRCUIT TI	2
A38,42	22	74H08	MICROCIRCUIT TI	2
A41	23	74H11	MICROCIRCUIT TI	1
A48,49	24	74S151	MICROCIRCUIT TI	2
A50,60	25	74H01	MICROCIRCUIT, TI	2
A54	26	74502	MICROCIRCUIT TI	1
A61	27	7414	MICROCIRCUIT TI	1
A64	28	74H106	MICROCIRCUIT TI	1
A65	29	74153	MICROCIRCUIT TI	1
A69	30	74161	MICROCIRCUIT TI	1
A62	31	K1100A	OSCILLATOR, 3.33 MHZ MOTORO	_A 1

PROPRIETARY NOTE ON SHEET 1 APPLIES TO ALL SHEETS			FILE: DSKCONO4.SIL		
TITLE	ALTOII ASSEMBLY, PRINTED WIRING BOARD	DWG. SIZE	DWG. 218092 NO.	SHEET REV.	
	DISK CONTROL MODULE	A4	SHEET 4 OF 20	В	

Xerox Corporation 701 South Aviati


		XEROX	
ITEM	PART NO.	DESCRIPTION	QTY.
33	AB#316A271	RESISTOR, NETWORK, DIP, 2700hm BRADBEY	1
34	AB#316A561	PESISTOR NETWORK DID FROOD ALLEN	, 1
35	750-81-R470	RESISTOR, NETWORK, DIP, 470ohm CTS	2
36	CB3905	RESISTOR,FILM,39ohm,5%,1/4W BRADEE	2
37	CB2015	RESISTOR,FILM,200ohm,5%,1/4W	5
38	CB2435	RESISTOR,FILM,24Kohm,5%,1/4W	2
39	CB1535	RESISTOR, FILM, 15Kohm, 5%, 1/4W	1
40	CB3035	RESISTOR,FILM,30Kohm,5%,1/4W	1
41	CB3315	RESISTOR,FILM,330ohm,5%,1/4W	2
42	CB5615	RESISTOR,FILM,560ohm,5%,1/4W	1
43	CB2715	RESISTOR,FILM,270ohm,5%,1/4W	1
44	CB1025	RESISTOR, FILM, 1 Kohm , 5%, 1/4W ALLEN	5
45		DRAITELE	<del> </del>
46	1N914	DIODE	2
47	IN5227	DIODE, ZENER TI	-
48			• • • • • • • • • • • • • • • • • • •
49	DC151	CAPACITOR, 150PF NYTRONIC	-
50	DC103	CAPACITOR, 0.01 uF NYTRONIC	
51	DC271	CAPACITOR270PF NYTRONIC	1
52	DC222	CAPACITOR,0.22uF,16V NYTRONIC	1
53	474M015POY	CAPACITORO.47uF,20%,15V MALLORY	Poblicies and
54	226M015P0Y	CAPACITOR,TANT., 22uF,20%,15V MALLORY	(0-940-4- ALABAN) - 1
55	UK10-503	CAPACITOR, 0.05UF, 10V CENTRALAB	31
56	514-AG11D	SOCKET, MICROCIRCUIT, AUGAT	7.1
57	516-AG11D	SOCKET, MICROCIRCUIT, AUGAT	7.2
58	156111-005	RIVET	
59	216250	EXTRACTOR	2
60	216242	STIFFENER	1
			************
			<b></b>
. I	L	<b>L</b>	1.
	33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59	33 AB#316A271 34 AB#316A561 35 750-81-R470 36 CB3905 37 CB2015 38 CB1535 39 CB3035 40 CB3315 42 CB3315 42 CB5615 43 CB2715 44 CB1025 44 IN914 47 IN5227 48 49 DC151 50 DC103 51 DC271 52 DC222 53 474M015POY 54 226M015POY 55 UK10-503 56 514-AG11D 57 516-AG11D 58 156111-005 59 216250	TIEM


	PROPRIETARY NOTE ON SHEET 1 APPLIES TO ALL SHEETS		FILE: DSKCONO5.SIL	
TITLE	ALTOII	DWG. SIZE	DWG. 218902	SHEET
	ASSEMBLY, PRINTED WIRING BOARD DISK CONTROL MODULE	A4	SHEET 5 OF 20	9


Xerox Corporation 701 South Aviation

ation			XEROX	
Ation BOLLEYAICAL REF. DESIGNATIONS	ITEM	PART NO.	DESCRIPTION	QTY.
A9	33	AB#316A271	RESISTOR, NETWORK, DIP, 2700hm BRADREY	1
A8	34	AB#316A561		1
A90,91	35	750-81-R470	RESISTOR, NETWORK, DIP, 470ohm CTS	2
R1,R2	36	CB3905	RESISTOR, FILM, 390hm, 5%, 1/4W BRADREY	2
R3,4,5,6,12	37	CB2015	RESISTOR,FILM,200ohm,5%,1/4W	5
R7,8	38	CB2435	RESISTOR,FILM,24Kohm,5%,1/4W	2
R9	39	CB1535	RESISTOR,FILM,15Kohm,5%,1/4W	1
R10	40	CB3035	RESISTOR,FILM,30Kohm,5%,1/4W	1
R11,20	41	CB3315	RESISTOR,FILM,330ohm,5%,1/4W	2
R18	42	CB5615	RESISTOR,FILM,560ohm,5%,1/4W	1
R19	43	CB2715	RESISTOR,FILM,270ohm,5%,1/4W	1
R13,14,15,16,17	44	CB1025	RESISTOR, FILM, 1 Kohm , 5%, 1/4W BRADREY	5
	45			
CR1,CR2	46	1N914	DIODE TI	2
VR1	47	IN5227	DIODE, ZENER TI	1
	48			
C1	49	DC151	CAPACITOR, 150PF NYTRONIC	1
C2,4	50	DC103	CAPACITOR, 0.01uF NYTRONIC	2
C5	51	DC271	CAPACITOR270PF NYTRONIC	1
C80	52	DC222	CAPACITOR, 0.22 uF, 16V NYTRONIC	1
C3	53	474M015P0Y	CAPACITORO.47uF,20%,15V MALLORY	1
C6	54	226M015P0Y	CAPACITOR, TANT., 22uF, 20%, 15V MALLORY	1
C11-17,19,21-37,40, 41,43-54,56-60,	55	UK10-503	CAPACITOR, 0.05UF, 10V CENTRALAB	61
62-75,77-79				
	56	514-AG11D	SOCKET, MICROCIRCUIT, AUGAT	31
	57	516-AG11D	SOCKET, MICROCIRCUIT, AUGAT	32
·	58	156111-005	RIVET	2
	59	216250	EXTRACTOR	2
	60	216242	STIFFENER	1

√						
PROPRIETARY NOTE ON SHEET 1 APPLIES TO ALL SHEETS			FILE: DSKCONO5.SIL			
TITLE	ALTOII	DWG.	DWG. 218902 NO.	SHEET REV.		
	ASSEMBLY, PRINTED WIRING BOARD DISK CONTROL MODULE	A4	SHEET 5 OF 20	В		








BUS(00) 1 BUS(02) 2 BUS(03) 3 BUS(04) 4 BUS(05) 5 BUS(06) 6 BUS(07) 7 BUS(08) 8	RPULL16 RP1 = VCC RP2 RP15 RP3 RP14 RP4 RP13 RP5 RP12 RP6 RP11 RP7 RP10 RP8 RP9 u9	15 BUS(15) 14 BUS(14) 13 BUS(13) 12 BUS(12) 11 BUS(11) 10 BUS(10) 9 BUS(09)
VCC	16 u9x	

### **BUSS BUFFER**


### **BUS BUFFERS**

XEROX Project	ASSEMBLY,P.W	File	Designer	Rev	Date	Page
SPG ALTOII	DISK CONTROL MODULE	DskCon06.sil	FREEMAN	В	9/22/80	06




**Power on Reset** 

XEROX	Project	ASSEMBLY, P.W	File	Designer	Rev	Date	Page
SPG	ALTOII	DISK CONTROL MODULE	DskCon07.sil	FREEMAN	В	9/25/80	07




Write S/R


	and the second second	and the Committee of th	the state of the s	and the second second second second			
XEROX	Project	ASSEMBLY.P.W.	File	Designer	Rev	Date	Page
SPG	ALTOII	DISK CONTROL MODULE	DskCon08.sil	FREEMAN	В	9/25/80	ว8



READ S/R


50 * Street	en de la companya de	gradegradegradedapid gradina i saminya	SQL Transport 1975 Constitution in			and the comment of the contract of
XEROX Project	ASSEMBLY, P.W.	File	Designer	Rev	Date	Page
SPG ALTOII	DISK CONTROL MODULE	DskCon09.sil	FREEMAN	В	9/22/80	09






COMP. AND REG.

XEROX	Project	ASSEMBLY, P.W.	File	Designer	Rev	Date	Page
SPG	ALTO II	DISK CONTROL MODULE	DskCon10.sil	FREEMAN	В	9/26/80	10
L	<u> </u>			CONTROL OF THE CONTRO	<u> </u>		




**STATUS** 

ı	XEROX	Project	ASSEMBLY, P.W.	File	Designer	Rev	Date	Page
	SPG	ALTO II	DISK CONTROL MODULE	DskCon11.SIL	FREEMAN	В	9/26/80	11




			and the same was an account to	·		<del> </del>	·
XEROX	Project	ASSEMBLY, P.	1 file	Designer	∃ev	Cate	Page
SPG	ALTO II	DISK CONTROL W	OskCon12 ad	FREEMAN	3	9/38/30	72




STROBE, SEEK ERRORS

XEROX	Project	ASSEMBLY, P.W.	File	Designer	Rev	Date	Page
SPG	ALTO II	DISK CONTROL MODULE	DskCon13.sil	FREEMAN	В	9/26/80	13
<u> </u>	<u> </u>		<u> </u>	L	L	<u> </u>	L.,




### DATAHANDLING

XEROX	Project	ASSEMBLY, P.W.	File	Designer	Rev	Date	False
SPG	ALTOII	DISK CONTROL MODULE	ÐakCan i 4.sii	FREEMAN	•	9/26/80	




### **Address Modifiers**


<del></del>		and the second s					
XEROX	Project	ASSEMBLY, P.W.	File	Designer	Rev	Date	Page
SPG	ALTOII	DISK CONTROL MODULE	DskCon15.sil	JSTEWART	В	9/29/80	15




SECTOR, ERROR WARE SE

XEROX Project	ASSEMBLY, P.W.	File	Desi <b>gne</b> r	Rev	Date	Page
SPG ALTO II	DISK CONTROL MODULE	େkCon16.∌iଧ	FREEMAN	2	9/24 30	16









F DECODE, CLOCKS

XEROX Project	ASSEMBLY, P.W	File	Designer	Rev	Date	Page
SPG ALTO II	DISK CONTROL MODULE	DskCon17.SIL	FREEMAN	В	9/26/80	17



### **DISK ADDRESSING**

XEROX	Project	ASSEMBLY, P.W.	File	Designer	Rev	) Date	Page
SPG	ALTO II	DISK CONTROL MODULE	DskCon18.sil	FREEMAN	В	<b>5/</b> 26/30	18
						i.	1



# INTERNAL DISC CABLE WIRE LIST (Disc Control Module to Disc Drive)

Disc Drive Connector	Disc Control Module Connector	Signal Name
A B	2 3	Read Clock Write Data & Clock
Č	38	Read Data
Ď	1 or 40	Ground
Ē	39	Read Gate
F	4	Ready to Seek, Read, or Write
H	34	Write Protect Input
J	37	Track Address - bit 8
K	35	Erase Gate
L M	5 36	Select Line - Unit 1
N N	6	High Density Indication Track Address - bit 2
P	33	Write Protect Status Indication
R	7	Select Line - Unit 2
S	32	Pseudo Sector Mark
T	8	Track Address - bit 64
Ü	31	File Ready
V	9	Select Line - Unit 3
W	30	Sector Mark
X Y	10 29	Track Address - bit 16
Ž	11	Index Mark Select Line - Unit 4
ĀA	28	Head Select
BB	12	Track Address - bit 128
CC	27	Sector Address - bit 1
DD	1 or 40	Ground
EE	26	Write Gate
FF	13	Track Address - bit 32
HH JJ	25	Write Check
KK	14 24	Sector Address - bit 2 Sector Address - bit 4
LL LL	24 15	Track Address - bit 1
MM	23	Sector Address - bit 8
NN	16	Address Acknowledge
PP	No Connection	OPEN LINE
RR	19	Track Address - bit 4
SS	22	Strobe
TT	17	Seek Incomplete
UU	21	Sector Address - bit 16
VV WW	20 1 or 40	Restore
w w XX	1 or 40 18	Ground
$\Lambda\Lambda$	10	Logical Address Interlock

### TRACK "O" ADJUSTMENT

### 1) USING THE SEEK EXERCISER

- A) LOAD SCRATCH PACK OR C. E. ALIGNMENT PACK AND BRING UP TO READY STATE.
- B) SCOPE CONNECTIONS AND SETUP AS FOLLOWS (TEKTRONIX MODEL 465):

X AXIS (CHANNEL # 1) AT TP1 ON J1 MODULE.

X AXIS (CHANNEL # 1) VOLTS PER DIVISION AT 2.0

Y AXIS (CHANNEL #2) AT TP2 ON J1 MODULE.

Y AXIS (CHANNEL #2) VOLTS PER DIVISION AT 2.0

TIME PER DIVISION ON X-Y

C) SETUP THE SEEK EXERCISER AS FOLLOWS:

ADDRESS 1 AND 2: ALL SWITCHS TO "OFF" POSITION

RESTORE: "ON" POSITION

START: "START" POSITION

STEP MODE: "STOP" POSITION (CONTINUOUS)

CYCLE RATE: FULLY C/W

- D) ADDRESS 2, BIT "1" TO "ON" POSITION.
- E) POSITION SCOPE PATTERN IN CENTER OF DISPLAY.
- F) ADDRESS 2, BIT "1" TO "OFF" POSITION.
- G) DOES CONTINUOUS RESTORE OPERATION. ADJUST ECCENTRIC (TT), (FIGURE 5-7 VIEW E OF DIABLO MAINTENANCE MANUAL) FOR PATTERN TO BE 135 DEGREES + OR 10 DEGREES. SEE FIGURE 5-8 OF THE DIABLO MAINTANENCE MANUAL FOR SCOPE PRESENTATION.

### 2) USING THE DIEX PROGRAM

WARNING: DO NOT ENABLE WRITING!

TO DISABLE WRITING: AFTER BOOTING DIEX, HIT THE "RETURN" KEY.

- A) BOOT DIEX, EITHER FROM THE NET OR DISC PACK. DISABLE WRITING!
- B) LOAD SCRATCH PACK OR C. E. ALIGNMENT PACK AND BRING UP TO READY STATE.
- C) SCOPE CONNECTIONS AND SETUP AS FOLLOWS (TEKTRONIX MODEL 465):

X AXIS (CHANNEL # 1) AT TP1 ON J1 MODULE.

X AXIS (CHANNEL # 1) VOLTS PER DIVISION AT 2.0

Y AXIS (CHANNEL #2) AT TP2 ON J1 MODULE.

Y AXIS (CHANNEL #2) VOLTS PER DIVISION AT 2.0

TIME PER DIVISION ON X-Y

- D) SELECT "RESTORE DISK" USING MIDDLE MOUSE BUTTON.
- E) POSITION SCOPE PATTERN IN CENTER OF DISPLAY.
- F) DOES CONTINUOUS RESTORE OPERATION. ADJUST ECCENTRIC (TT), (FIGURE 5-7 VIEW E OF DIABLO MAINTENANCE MANUAL) FOR PATTERN TO BE 135 DEGREES + OR 10 DEGREES. SEE FIGURE 5-8 OF THE DIABLO MAINTANENCE MANUAL FOR SCOPE PRESENTATION.
- G) SELECT "RESTORE DISK" USING LEFT MOUSE BUTTON.

### **READ/WRITE HEADS ADJUSTMENT**

### 1) USING THE SEEK EXERCISER

- A) LOAD C. E. ALIGNMENT PACK AND BRING UP TO READY STATE.
- B) SCOPE CONNECTIONS AND SETUP AS FOLLOWS (TEKTRONIX MODEL 465):

CHANNEL # 1 AT TP6 ON J9 MODULE.

CHANNEL #1 VOLTS PER DIVISION ON 2.0

CHANNEL #2 AT TP2 ON J10 MODULE.

CHANNEL #2 VOLTS PER DIVISION ON .2

TIME PER DIVISION ON 5 m sec.

TRIGGER ON: CHANNEL # 1 (-) SLOPE

C) SETUP THE SEEK EXERCISER AS FOLLOWS:

ADDRESS # 1 SWITCHES IN THE "OFF" POSITION.

ADDRESS #2 SWITCHES 64, 32, 8, 1 IN THE "ON" POSITION.

ALL OTHER ADDRESS #2 SWITCHES IN THE "OFF" POSITION.

RESTORE: "ON" POSITION
START: "START" POSITION
STEP MODE: "STEP" POSITION

CYCLE RATE: MIDWAY BETWEEN C/W AND CC/W

- D) DO A SEEK TO CYLINDER 105 BY DEPRESSING AND RELEASING THE "STEP PUSHBUTTON" UNTIL THE HEADS ARE AT CYLINDER 105.
- E) ADJUST HEADS FOR EQUAL VALLEYS USING THE ADJUSTMENT SCREWS (RR) AND (SS), (FIGURE 5-7 VIEW E
  OF DIABLO MAINTANENCE MANUAL). SEE FIGURE 5-9 AND 5-10 OF THE DIABLO MAINTANENCE MANUAL FOR
  SCOPE PRESENTATION
- F) IF ADJUSTMENT IS NECESSARY THE HEAD CLAMP SCREWS SHOULD BE TIGHTEN AS BELOW:

SEE FIGURE 5-7 VIEW E OF THE DIABLO MAINTANENCE MANUAL.

SINGLE HEAD CLAMP SCREWS (MM) AND (NN): 26 in/ozs. OF TORQUE.

DUAL HEAD CLAMP SCREW (PP): 50 in/ozs. OF TORQUE.

### 2) USING THE DIEX PROGRAM

WARNING: DO NOT ENABLE WRITING!

TO DISABLE WRITING: AFTER BOOTING DIEX, HIT THE "RETURN" KEY.

- A) BOOT DIEX, EITHER FROM THE NET OR DISC PACK. DISABLE WRITING!
- B) LOAD C. E. ALIGNMENT PACK AND BRING UP TO READY STATE.
- C) SCOPE CONNECTIONS AND SETUP AS FOLLOWS (TEXTRONIX MODEL 465):

CHANNEL # 1 AT TP6 ON J9 MODULE.

CHANNEL #1 VOLTS PER DIVISION ON 2.0

CHANNEL #2 AT TP2 ON J10 MODULE.

CHANNEL #2 VOLTS PER DIVISION ON .2

TIME PER DIVISION ON 5 m sec.

TRIGGER ON: CHANNEL #1 (-) SLOPE

- D) SELECT "FIRST CYL = 00" AND TYPE 105, THEN DEPRESS AND RELEASE THE LEFT MOUSE BUTTON.
- E) SELECT "LAST CYL = 202" THEN DEPRESS AND RELEASE THE LEFT MOUSE BUTTON.
- F) SELECT "RESTORE DISK" USING THE LEFT MOUSE BUTTON, UNTIL THE DISC DRIVE STATUS REPORTS CYLINDER 105.
- G) ADJUST HEADS FOR EQUAL VALLEYS USING THE ADJUSTMENT SCREWS (RR) AND (SS), (FIGURE 5-7 VIEW E OF DIABLO MAINTANENCE MANUAL). SEE FIGURE 5-9 AND 5-10 OF THE DIABLO MAINTANENCE MANUAL FOR SCOPE PRESENTATION
- H) IF ADJUSTMENT IS NECESSARY THE HEAD CLAMP SCREWS SHOULD BE TIGHTEN AS BELOW: SEE FIGURE 5-7 VIEW E OF THE DIABLO MAINTANENCE MANUAL.

SINGLE HEAD CLAMP SCREWS (MM) AND (NN): 26 in/ozs. OF TORQUE.

DUAL HEAD CLAMP SCREW (PP): 50 in/ozs. OF TORQUE.

### TRANSDUCER ADJUSTMENT

### 1) USING THE SEEK EXERCISER

- A) LOAD C. E. ALIGNMENT PACK AND BRING UP TO READY STATE.
- B) SCOPE CONNECTIONS AND SETUP AS FOLLOWS (TEKTRONIX MODEL 465):

CHANNEL # 1 AT TP6 ON J9 MODULE.

**CHANNEL #1 VOLTS PER DIVISION ON 2.0** 

CHANNEL #2 AT TP2 ON J10 MODULE.

CHANNEL #2 VOLTS PER DIVISION ON 2.0

TIME PER DIVISION ON 5 micro. sec.

TRIGGER ON: CHANNEL #1(-) SLOPE

C) SETUP THE SEEK EXERCISER AS FOLLOWS:

ADDRESS # 1 SWITCHES IN THE "OFF" POSITION.

ADDRESS #2 SWITCHES 64, 32, 4 IN THE "ON" POSITION.

ALL OTHER ADDRESS # 2 SWITCHES IN THE "OFF" POSITION.

**RESTORE: "ON" POSITION** 

START: "START" POSITION

STEP MODE: "STEP" POSITION

CYCLE RATE: MIDWAY BETWEEN C/W AND CC/W

- D) DO A SEEK TO CYLINDER 100 BY DEPRESSING AND RELEASING THE "STEP PUSHBUTTON" UNTIL THE HEADS ARE AT CYLINDER 100.
- E) ALTERNATELY SELECT THE HEADS AND ADJUST THE SECTOR TRANSDUCER, (FIGURE 5-13 A AND B OF DIABLO MAINTANENCE MANUAL) TO POSITION THE FIRST PEAK OF THE ISOLATED PLUSE FROM EACH OF THE HEADS SYMMETRICALLY AROUND THE 30 micro. sec. POINT. SEE FIGURE 5-13 C OF THE DIABLO MAINTANENCE MANUAL FOR SCOPE PRESENTATION. THE SEPARATION BETWEEN THE HEADS MUST BE LESS THAN 10 micro. sec.

### 2) USING THE DIEX PROGRAM

WARNING: DO NOT ENABLE WRITING!

TO DISABLE WRITING: AFTER BOOTING DIEX, HIT THE "RETURN" KEY.

- A) BOOT DIEX, EITHER FROM THE NET OR DISC PACK. DISABLE WRITING!
- B) LOAD C. E. ALIGNMENT PACK AND BRING UP TO READY STATE.
- C) SCOPE CONNECTIONS AND SETUP AS FOLLOWS (TEKTRONIX MODEL 465):

CHANNEL # 1 AT TP6 ON J9 MODULE.

CHANNEL # 1 VOLTS PER DIVISION ON 2.0

CHANNEL #2 AT TP2 ON J10 MODULE.

CHANNEL #2 VOLTS PER DIVISION ON 2.0

TIME PER DIVISION ON 5 micro. sec.

TRIGGER ON: CHANNEL #1(-) SLOPE

- D) SELECT "FIRST CYL = 105" AND TYPE 100, THEN DEPRESS AND RELEASE THE LEFT MOUSE BUTTON.
- E) SELECT "LAST CYL = 105" THEN DEPRESS AND RELEASE THE LEFT MOUSE BUTTON.
- F) SELECT "RESTORE DISK" USING THE LEFT MOUSE BUTTON, UNTIL THE DISC DRIVE STATUS REPORTS CYLINDER 100.
- G) ALTERNATELY SELECT THE HEADS AND ADJUST THE SECTOR TRANSDUCER, (FIGURE 5-13 A AND B OF DIABLO MAINTANENCE MANUAL) TO POSITION THE FIRST PEAK OF THE ISOLATED PLUSE FROM EACH OF THE HEADS SYMMETRICALLY AROUND THE 30 micro. sec. POINT. SEE FIGURE 5-13 C OF THE DIABLO MAINTANENCE MANUAL FOR SCOPE PRESENTATION. THE SEPARATION BETWEEN THE HEADS MUST BE LESS THAN 10 micro. sec.

# MODEL 31 DISC DRIVE DATA GATE RETROFIT OF J10 MODULE

# 1) TO CHECK THE DATA GATE

A) SCOPE CONNECTIONS AND SETUP AS FOLLOWS (TEXTRONIX MODEL 465):

CHANNEL # 1 AT TP3 ON J10 MODULE

CHANNEL # 1 VOLTS PER DIVISION AT 2.0

CHANNEL #2 AT TP5 ON J10 MODULE

CHANNEL #2 VOLTS PER DIVISION AT 2.0

TIME PER DIVISION AT .05 micro. sec.

TRIGGER ON: CHANNEL # 1 (-) SLOPE

- B) LOAD SCRATCH PACK AND BRING UP TO READY STATE.
- C) POSITION CHANNEL # 1 SCOPE TRACE SO THAT THE 50% POINT OF THE FALLING EDGE IS ON THE LEFT SIDE OF THE SCOPE DISPLAY.
- D) THERE SHOULD BE TWO FALLING EDGES OF CHANNEL # 2's SCOPE TRACE. THE 50% POINT OF FALLING EDGES SHOULD BE APPROXIMATELY 440 nsec. AND 450 nsec.

NOTE: THE FACTORY SETS THE DATA GATE AT 450 nsec. AND 470 nsec. BUT SPG
MANUFACTURING MODIFIES THIS TO APPROXIMATELY 440 nsec. AND 460 nsec.

### 2) TO VERIFY IF DATA GATE IS CORRECT

- A) BOOT DIEX, EITHER FROM THE NET OR DISC PACK. ENABLE WRITING.
- B) LOAD SCRATCH PACK AND BRING UP TO READY STATE.
- C) RUN DIEX AS YOU NORMALLY WOULD TO CHECK OUT THE MODEL 31 DISC DRIVE.

  WHILE RUNNING "INIT FULL TEST" MONITOR THE DATA GATE AND VERIFY THAT DURING

  THE READ PASS THE SCOPE PRESENTATION IS NOT JUMPING AROUND. CHECKSUM ERRORS

  (04 ERRORS) THAT OCCUR AND ARE TOTALLY RANDOM WITH REGUARDS TO CYLINDER,

  HEAD, AND SECTOR COULD BE CONSIDERED AS ERRORS CAUSED BY AN INCORRECT

  DATA GATE.

### 3) TO MODIFY THE DATA GATE

- A) NOTE THE VALUES OF RESISTORS H53 AND F28
- B) TO INCREASE THE TIME OF THE DATA GATE, RESISTORS H53 AND F28 NEED TO BE DECREASED IN VALUE.
- C) FIND SOME RESISTORS THAT ARE STANDARD VALUES ABOVE OR BELOW THE VALUE NOTED IN STEP A. REPLACE RESISTORS H53 AND F28 WITH THE APPROPRIATE VALUE RESISTORS.
- D) RETEST THE DATA GATE TO INSURE IT IS CORRECT.

# MODEL 31 DISC DRIVE SPECIAL TOOLS


XEROX P/N	DESCRIPTION	VENDOR P/N
600T1372	ALIGNMENT CARTRIDGE	70268
600T1373	SEEK RESTORE EXERCISER	11142
600T1380	TEST TERMINATOR	11075
600T1374	EXTENDER BOARD	11040-01
600T1375	BAR TOOL	15172
600T1376	CONE TOOL	15171
600T1396	TORQUE WRENCH SET	••••
ABOVE TORQU	UE WRENCH SET CONTAINS THE FOLLOWING	<b>G</b> :
600T1378	TORQUE WRENCH HANDLE	70342
600T1379	EXTENDER XCELITE MOD.	70345-01
600T1381	BIT XCELITE 99-22	70343
600T383	BIT XCELITE 990764	••••

# TERMINATOR SERIES 30

# P/N 11175-03

# FOR ALTO II DISC DRIVE (DIABLO)

### FEMALE CONNECTOR



Leave the following resistors on the terminator, clip off the rest:

E1	D23	J11
E2		J13
E7		J14
E8		J16
F23		

Leave on the following caps, clip off the rest:

A22 H1

This leaves the following pins terminated:


A,C,H,S,V

# TERMINATOR SERIES 30

# P/N 11174-03

# FOR ALTO II DISC DRIVE (DIABLO)

# MALE CONNECTOR



Leave the following resistors on the terminator, clip off the rest:

D4	E29	J18	H25
D6		J19	H29
		J24	
		J25	
		J27	

Leave on the following caps, clip off the rest:

A22 H1


This leaves the following pins terminated:

A,C,H,S,V


### **DISC DRIVE DAISY CHAINING DIAGRAM**


### **NORMAL VIEW (BACK)**

### ONE DRIVE




### TWO DRIVES






THIS CONFIGURATION REQUIRES ONLY A CABLE P/N 11245-XX

### TWO DRIVES





THIS CONFIGURATION REQUIRES A CABLE P/N 11105-XX AND TERMINATOR P/N 11175-03